



HOW TO APPLY SUPER MAGNETIC PAINT

- 1 MEASURE THE AREA**
- Carefully measure the area you wish to cover and ensure you have enough paint. This tin covers 5 sq. metres / 54 sq. ft. with 4 coats.

- 2 PREPARE THE SURFACE**
- Ensure the surface is clean and dry. Check and fill any holes or cracks in the surface with a normal decorator's filler.
 - Apply one coat of **Smart White Primer** to prepare the surface.

- 3 STIR**
- Stir until liquid.

- 4 APPLY MAGNETIC PAINT**
- We recommend 4 coats of paint.
 - Use roller or brush to apply. (If roller, use a short pile sleeve to ensure a smooth finish).
 - Apply first coat by applying a smooth even coat.
 - Allow to dry.

- 5 SAND THE SURFACE**
- Lightly sand between coats. Ensure finished surface is smooth.

- 6 ALLOW TO DRY**
- Allow the surface to dry for a minimum of 24 hours before overcoating or applying a paint colour, digital print or wallpaper of your choice.

- 7 MAGNETS**
- For best performance, we recommend using **Smart Neo-Magnets** (available from www.smartersurfaces.com) or any high quality neodymium magnets.

Note:

Ordinary household magnets are not suitable.

GET EVEN MORE FUNCTIONALITY

Consider adding dry erase functionality with **Smart Whiteboard Wallpaper** or **Smart Whiteboard Paint**.

Product Liability Clause

The sale of our products is subject to our General Terms and Conditions available on www.smartersurfaces.com



Support:

Email:
support@smartersurfaces.com

Website:
www.smartersurfaces.com