



SUPER MAGNETIC PAINT

APPLICATION GUIDE

HOW TO APPLY SUPER MAGNETIC PAINT

1 MEASURE THE AREA

- Carefully measure the area you wish to cover and ensure you have enough paint. This tin covers 6m²/ 65 sq. ft. with 4 coats.

2 PREPARE THE SURFACE

- Ensure the surface is clean and dry. Check and fill any holes or cracks in the surface with a normal decorator's filler.
- Apply one coat of **Smart White Primer** to prepare the surface.

3 STIR

- Stir until liquid.

4 APPLY MAGNETIC PAINT

- We recommend 4 coats of paint.
- Use roller or brush to apply. (If roller, use a short pile sleeve to ensure a smooth finish).
- Apply first coat by applying a smooth even coat.
- Allow to dry.

5 SAND THE SURFACE

- Lightly sand between coats. Ensure finished surface is smooth.

6 ALLOW TO DRY

- Allow the surface to dry for a minimum of 24 hours before overcoating or applying a paint colour, digital print or wallpaper of your choice.

7 MAGNETS

- For best performance, we recommend using **Smart Neo-Magnets** (available from www.smartersurfaces.com) or any high quality neodymium magnets.

Note:

Ordinary household magnets are not suitable.

GET EVEN MORE FUNCTIONALITY


Consider adding dry erase functionality with **Smart Whiteboard Wallpaper** or **Smart Whiteboard Paint**.

PRODUCT LIABILITY CLAUSE

The sale of our products is subject to our General Terms and Conditions available on www.smartersurfaces.com

SUPPORT

 **EMAIL:**
support@smartersurfaces.com

 **PHONE (IRE):**
+353 1 412 6200

 **WEBSITE:**
www.smartersurfaces.com